

# Museum BroekerVeiling

## Instructie elektrische boot Museum BroekerVeiling

### Na het instappen in de boot:

- 1 laadsnoer uit stopcontact en in de boot leggen
- 2 joystick rechtop zetten
- 3 sleuteltje in contact, een kwart slag draaien en zo de motor "Aan", zetten
- 4 wachten tot Display 24 Volt (of meer) aangeeft en "Bat" op 50% (of meer) staat.

Tijdens het varen NOOIT de hoofdschakelaar uitzetten (calamiteiten voorbehouden)

### Na het varen (volgorde)

- 1 joystick rechtop zetten
- 2 sleuteltje kwartslag terug draaien en zo motor "Uit" zetten
- 3 laadsnoer niet aansluiten, in de boot laten liggen.
- 4 **sleutel uitnemen en afgeven bij de balie van Museum BroekerVeiling!**

### Algemeen:

- De stuurman is verantwoordelijk voor de boot en de opvarenden!
- De stuurman dient ten minste 18 jaar oud te zijn!
- Verdeel het aantal passagiers over de gehele boot, niet teveel achterin.
- Pas op dat er geen ledematen tussen wal en de boot komen.
- Net als op de weg, rechts gaat voor, hier geldt ook, groot gaat voor klein!
- Vaar aan de rechteroever ongeveer 1½ meter van de wal (stuurboordwal).
- Vaar niet vlak langs de oever, de schroef kan de grond raken.
- Vaar niet op plaatsen met waterplanten, de planten gaan om het staartstuk hangen.
- Als er toch planten om de schroef blijken te hangen, meer de boot af, schakel de motor uit en haal de schroef leeg.
- Als u langs de scheepswerf vaart, let dan op dat de rails van de helling doorloopt tot in het water. Houd afstand!

### Varen:

Stuurman/ vrouw; ga achter de motor zitten

Geef 50% vermogen (meer is niet nodig, maar kost wel heel veel meer energie)

Stuur en vaar zo rustig mogelijk. Een boot reageert langzaam. Probeer ver vooruit te denken.

In noodgevallen bel dan met Museum BroekerVeiling: 0226-313807.

**Wij helpen u graag maar assistentie door verwijtbaar gedrag kan in rekening worden gebracht!**

# Museum BroekerVeiling

## Instructions on use of electrical pram Museum BroekerVeiling

### After boarding the pram:

- 1 take the plug out of the socket and put the electrical cord in the pram
- 2 ensure the joystick points upwards
- 3 put the key in the ignition, turn one quarter until the motor is "On"
- 4 wait until the display indicates 24 Volt (or over) and en "Bat" is set to 50% (or over)

NEVER switch off the main switch while sailing (except in emergencies)

### After you return from your sailing trip

- 1 ensure the joystick points upwards
- 2 turn the key back one quarter so the motor is "Off"
- 3 leave the electrical cord in the boat, do not plug it into the socket
- 4 **take out the key and return it to the front desk at Museum BroekerVeiling!**

### General:

- The captain is responsible for the pram and all its passengers!
- The captain has to be at least 18 years of age!
- Please divide the number of passengers over the entire boat.
- Make sure to keep hands and feet inside the barge, so no limbs are caught between the shore and the pram.
- Traffic from the right goes first (just like on the road). Also, big boats go before small prams!
- Please keep to the right, with a distance of about 1 ½ metres from the pram to the shore (starboard side).
- Do not sail too close to the shore, as the screw might then hit the bottom of the canal.
- Do not steer through places with dense growths of water plants. The plants might get entangled in the screw.
- If at any point you suspect water plants might be entangled in the screw, shut down the engine (key switch "Off"), ensure the joystick points upright, reach down over the back of the pram and gently pry away any debris entangled around the screw.
- If you pass the shipyard please know that the rails of the ramp extend a good ways under water. Keep your distance!

### Sailing the pram:

The captain sits behind the casing of the electrical motor.

Do not exceed to more than 50% of power using the joystick (more is not necessary but does cost a lot of battery power).

Steer and sail calmly. The boat reacts slowly, please try and think ahead.

In case of emergency, please contact Museum BroekerVeiling by calling +31 226 313 807.

**We are happy to help, but we might bill you in case assistance is needed due to careless behaviour on your part!**